

Sick Bike Parts.com

Chain Adjuster Installation Instructions



Required Tools:

Hacksaw or moto tool with cut off disc

Wrenches

Step 1

Remove the 2 nuts from your lower motor mount clamp

Loosen your upper motor mount clamp enough so it will slide on the seat tube

Step 2

Install one of the 2 adjuster brackets as shown in the figure above

Install the 2 nuts onto the lower motor mount clamp but do not tighten them

Step 3

Install the new clamp and lower adjuster bracket, be sure to leave this loose

Measure the distance between the parallel flat surfaces of the 2 adjuster brackets

Step 4

Add 1.5 inches to your measurement and cut the adjuster rod to that length

Note:

If you are not used to cutting threads you may want to put the 4 nuts in the middle of the rod so you won't have to try and thread them onto an unfinished threaded end

Step 5

With the 4 nuts close to the middle of the rod, add a washer (not shown in photo) to the top and bottom of the nuts

Slide the rod into the hole of the bracket attached to the lower motor mount clamp

Position the lower adjuster as seen in the photo and slide the other end of the adjuster rod into the hole

Start threading the outer most nuts toward the adjuster brackets until they almost touch

Step 6

Position your lower adjuster bracket and clamp against the bottom tube and tighten the clamp bolts

Thread the remaining 2 nuts toward the two outer nuts

Tighten the upper two nuts against each other using 2 wrenches so they won't loosen

Step 7

With your two motor mount clamps just loose enough for your engine to slide, start threading the lower nut against the bottom adjuster bracket until your chain becomes tight

Tighten both of your motor mount clamps

Tighten the remaining nut on the adjuster rod against the lower nut with two wrenches to keep it from coming loose.

Step 8

Go have some Fun!